

INDOOR COVERED HALF DOME MIRROR INSTALLATION GUIDE

1. Measure the distance between the two hole slots on the wall (300mm apart)
2. Screw the supplied wall screws into the wall or insert the supplied wall plugs into the wall, making sure they are level and the screws are protruding out from the wall approx 13mm.
3. Slot the mirror onto the screws to hang.
4. When the job is complete, remove the protective film from the face.



Measure distance apart for
screws on the wall



Wall Screws and
Plugs Supplied

