

INDOOR SPACE SAVER MIRROR INSTALLATION GUIDE

1. Decide the appropriate place to site the mirror to give maximum vision.
2. Fix J-Bracket to wall or ceiling using suitable fixing hardware (ie: screws, bolts). Allowing enough room to get the mirror on to the J-Bracket.
3. Thread the adaptor through the Aluminium Bar into the Hex Nut and tighten.
4. Peel protective film off around the immediate edge of the mirror.
5. Slide the adaptor and mirror over the J-Bracket and adjust mirror to the desired position.
6. Tighten the locking bolt on the adaptor securely.

