

## ECONOMY INDOOR MIRROR INSTALLATION GUIDE

1. Decide the appropriate place to site the mirror to give maximum vision.
2. Fix J-Bracket to wall or ceiling using suitable mounting hardware (ie: screws, bolts). Allowing enough room to slide the mirror on to the J-Bracket.
3. Unscrew the adaptor from the J-Bracket. Thread the adaptor through the Aluminum Bar into the Hex Nut and tighten.
4. Peel protective film off around the immediate edge of the mirror.
5. Slide the adaptor and mirror over the J-Bracket and adjust mirror to the desired position.
6. Tighten the locking bolt on the adaptor securely.
7. When the mirror is securely in position, totally remove the protective film from the mirror.

