

# Anti-Vandal Wall Mirrors

## Stainless Steel Anti-Vandal Vanity Mirror




7mm Counter-bore Holes



Button Head Torx Security Masonry Screw  
Size: 1/4" x 1 3/4" (6.35mm x 44.45mm)  
Driver Size: #27 Torx Security 1/4" (6.35mm) Hex Bit  
Drill Dia: 3/16" (4.76mm)

### Torx Screw Installation Guide:

- It is recommended to use a 3/16" (4.76mm) Straight Shank Tanged Bit to drill the hole.
- The hole must be at least 2" or 50mm overall depth and free of any debris.
- By using the #27, 1/4" (6.35mm) Hex Bit the special Hi-Lo thread literally taps into masonry materials.
- The high, sharp thread with its notched cutting edge cuts deeply and easily.
- The alternating low thread provides stability for fast, accurate driving.
- Torx screws are suitable for use in concrete, brick, or hollow block. Make sure the surface is flat and do not over-tighten screws.



## Stainless Steel Cleaning Instructions

Clean with soap and water and then with a soft, lint free, damp cloth.

### DO NOT USE:

- abrasives
- acids

### POLISH:

Using a commercial Stainless Steel Polish is NOT recommended as the protective layer will leave a residue on the highly polished mirror faces. Rubbing plain white flour on a dry stainless steel mirror face with a dry cloth will polish the mirror to its original brilliance.

### GRAFFITI REMOVAL:

Any graffiti should be removed from the mirror face as soon as possible and preferably within 24 hours with suitable lacquer thinners. Not all graffiti cleaning agents are suitable. Failure to use an approved cleaning agent may damage the mirror surface.